

Basic instruction on how to install your BAWLOCK™

A lock with 1/4"dia. X 1 1/2" long shackle works with the BAWLOCK.

INSTALLING THE PERMANENTE FLAT NUT IN YOUR FIN BOX

1. Remove / lift existing fin and fin flat nut out of fin box (A). Insert and position **BAWLOCK Flat Nut (B)** either in front or behind fin and fin flat nut position – where there's the most room. Replace fin flat nut and fin into fin box and secure. Note that **BAWLOCK Flat Nut (B)** stays in place – **in front or behind fin** - and is not removed. It will not affect your surfing or paddling.

LOCKING YOUR BOARD

2. When ready to lock your board, screw in **Retainer Insert (C)** into **Flat Nut (B)** until semi-flush with your fin block.
3. Put **Saddle (D)** over **Retainer Insert (C)** and align into slot of fin box (A).
4. Put your lock (not included), with 1/4" X 1 1/2" shackle, through holes of **Saddle (D)** and **Retainer Insert (C)**.
5. Put a cable or chain through the lock shackle after securing the cable or chain around a secure object (i.e. surf racks, D ring on truck, palm tree, etc.).

