

## INSTRUCTIONS FOR BAWRACK INSTALLATION (Simple)

### What you received in the box:

- 2 ea BAWRACKS® rails
- 4 ea 4 1/4" X 3" lag bolts
- 4 ea 1/4" flat washer
- 4 ea carriage bolt
- 4 ea wing nut
- 4 ea neoprene covered BAWRACKS® carriers (2 sets)

### What you need to install BAWRACKS®

- Power Drill
- 3/16" drill
- 7/16" open or closed end wrench **or** 7/16" socket w/ ratchet wrench

### Wall Installation:

- 1) Find studs in wall (must be mounted on studs to hold weight).
- 2) Mark both studs to the height you want racks ensuring they are both even and level.
- 3) Mark and drill 3/16" pilot holes into studs approximately 3" deep on top and bottom of each rail.
- 4) Recommended that square hole on rail face outward when mounting to wall. Insert 1/4" lag bolt with flat washer through the top holes and screw down snug into stud.
- 5) Ensure rails are level and plumb before securing bottom of rail. Screw down lower lag bolts until snug.

### Carrier installation

- Select BAWRACKS® carrier and pull back neoprene padding, insert carrier into rail track at desired level and insert carriage bolt through square hole, carrier hole and round rail hole.
- Tighten wing nut onto carriage bolt until snug and cover with neoprene padding.